

# LCD 2-WAY

Remote Start & Security System

**MODEL: KR-8800**

## Operation & Installation Manual



**Kopel**

## Remote Start & Security System






















**Köpel**

# Contents

Button Functions .....	2
Icon of LCD .....	3
Alarm Functions .....	4
Door lock(Arming)/Panic	Driver calling(Knock)
No chirp mode	Shock sensing
Door unlock(Disarming)	When input is triggered
Trunk unlock(Car finder)	Checking the vehicle status
Start Functions .....	6
Automatic vehicle	
Reservation of stick shift vehicle (Auto process)	
Reservation of stick shift vehicle (Manual process)	
Getting on the vehicle during remote start	
Start reservation of the LPG vehicle	
Getting on the vehicle during LPG start	Auto turbo function
Time reservation start setting	Valet mode
Vehicle selection mode	Repeat start operation
Setting Mode .....	11
Button hold	Start time setting
Signal check	Timer function
Buzzer ON/OFF	Siren ON/OFF
Alarm ON/OFF	Temperature check
Current time setting	LCD back light ON/OFF
Alarm time setting	Vibration mode
Convenient Functions .....	14
Aux-1 output	Convenience start
Aux-2 output	Cold & hot start
Smart access mode	
Code Learning .....	15
Transmitter code learning	Low battery indicator
RPM setup	
Program Setting .....	16
Program setting	Program reset
Program Menu .....	18
Installation .....	22
HARNESS WIRE CONNECTION GUIDE	
Digital Control Module(Optional) .....	26
Wiring Diagram .....	29


# Button Functions

Operation Button No. Icon		1time (one second)	2times (Double click)	Two seconds	Page	
1		Arming/Disarming (Lock/Unlock)	Arming/Disarming (No chirp mode)	Panic mode	4	
2		Stick reservation	Remote start OFF Convenience start(IG ON)	Remote start ON	6, 7, 14	
3		Car finder(Arm mode)	Shock sensing OFF (Two stage sensing OFF)	Trunk unlock	4, 5	
4		Vehicle status confirmation	Temperature check	Parking timer mode	5,13	
5	 LCD Lamp ON (1 time)	Continues (Setting mode)	2 seconds	HoL	Button hold ON	11
			4 seconds	SIG	Signal check ON	
			6 seconds	bur	Buzzer OFF	
			8 seconds	ALm	Alarm setting ON	
			10 seconds	CLOCK	Current time setting	12
			12 seconds	ALARM	Alarm time setting	
			14 seconds	START	Start time setting	
		3 times (Program setting mode)	Button 4	M	Move to next menu	16
			Button 3		Move to next function	
			Button 2		Setup OFF or selection	
Button 1			Setup ON or selection			
		Button 5	F	Setup finish		
1+2	 Two seconds	Vehicle selection mode(Ignition OFF, within 30 seconds)				9
		Button 1	Normal vehicles	Standby time setting for 4 seconds		
		Button 2	Diesel vehicles	Standby time setting for 8 seconds		
		Button 3	Special vehicles	Standby time setting for 8 seconds Re-Lock setting after remote start		
		Button 4	LPG vehicles	LPG function setting(30seconds delay)		
1+4	 Two seconds	Repeat start operation(8 times / 24 hours)			RPM setup (In valet mode)	10,15
5+3	 Two seconds	LCD back light ON/OFF	5+4	 Two seconds	Vibration mode ON	13
5->1		Siren ON->OFF (At the shock sensing)	5->2		Time reservation start setting	9,13
5->3		Aux-1 output(One way transmitter: Press button 4(*) for 2 seconds)				14
5->4		Aux-2 output(One way transmitter: Press button 4(*) for 2 times)				14
1+3	 Two seconds	Programming mode(One way TX, Ignition ON and within 30 seconds) Program reset(In valet mode)				16


 <b>ARM</b> 	Door lock(Arming) Signal check ON	<b>CLOCK</b>	Adjustment mode of current time
 <b>DIS ARM</b>	Door unlock (Disarming)	<b>ALARM</b>	Adjustment mode of alarm time
 <b>START</b>	Remote start	<b>START</b>	Adjustment mode of automatic start time
<b>TRUNK</b> 	Trunk unlock	<b>VALET</b> 	Valet mode
 <b>DOOR</b>	Door open		Battery status
 <b>SHOCK</b>	Shock sensing		Blink icon
 <b>CALL</b>	Call indicator (Knock)	<b>F</b>	Button hold Function mode
 <b>ALARM</b>	Wake-up alarm setting ON	<b>AM 10:00</b> <b>PM 10:00</b>	Time, Temperature Program menu
 <b>AUTO START</b>	Automatic start setting ON	 <b>TIMER</b>	Timer mode
	Siren OFF(When shock sensing)		RF transmit
	Buzzer OFF		Progressing time of the remote start
<b>ACCESS</b>	Smart access ON	<b>AUX1</b>	AUX-1
<b>TURBO</b>	Turbo ON	<b>AUX2</b>	AUX-2
<b>TEMP</b>	Temperature Start ON	<b>°C</b>	Temperature
<b>IIIERR</b>	Signal error		Vibration mode ON

# Alarm Functions

## Door lock(Arming)/Panic




- When turned Bypass ON, If door is open after 5 - 45 seconds when you arm by press door button, you will hear 3 chirps. (Arm delay time setting : Program 3-8, Bypass ON/OFF: Program 4-4, Arm cancel mode at door open: Program 4-8)



- No chirp mode**: If you press the button sequentially (Double click), door lock/unlock is operated without chirps.

## Door unlock(Disarming)



- If you don't open the door within 30sec after the disarming, the vehicle enters alarm mode again with the door is automatically locked.

## Trunk unlock(Car finder)



- When you unlock the trunk by the transmitter in the arm mode, the vehicle enters disarm mode. If you don't open the door within 30sec, the vehicle enters arm mode again.
- If you connect trunk pin switch, disarm is continually kept.
- Car finder function**: If you press the trunk button for 1sec in arm mode, you can confirm current status of vehicle with "Beep" sound and light.

## Driver calling(Knock)



"3 chirps"



Display

Knock the driver call sensor on the windshield of the vehicle.

- After arm delay time(5 - 45 seconds), this function is operated after 20 seconds. (Arm delay time default: 5 seconds, See the table 3-8.)

*Driver calling is stopped at the remote engine start.*

## Shock sensing



Shock sensing




The siren output for 30sec  
(Weak shock: Warning)



Display



Press the button to stop the siren

- After arm delay time(5 - 45 seconds), this function is operated after 20 seconds. (Arm delay time default: 5 seconds, See the table 3-8.)
- Shock sensing OFF: If you want shock sensor is OFF(1time) you need to press the trunk button  2times in arm mode. (Two stage sensor OFF : First time=weak shock, second time=strong shock)
- The sensor detects external shock either as high level or as low level.

You can adjust the sensitivity through testing.

*Shock sensing is stopped at the remote engine start.*

## When input is triggered



When the input is triggered in the arming mode



The siren output for 30sec



Door trigger



Trunk trigger



Hood, brake, IG trigger

- The siren will repeatedly output 4times for each 30sec if the door is opened.



Press the button to stop the siren

## Checking the vehicle status



Press the button for 1sec

Current status of vehicle is marked by icon

LCD back light ON



- ERR** This icon is turned on when it can't receive reception after operate transmitter.

# Start Functions

## Automatic vehicle

- 
- Gear should be located at the "P"
- Press the button for 2sec
- The engine start is operated after 4sec(see program 3-2,3-3)
- Display
- Light blink for 15 minutes after remote start and the engine start turn off automatically after the 15 minutes. (Progress time is marked to icon.) The buzzer sound is outputted from the transmitter when the remaining start time is 5 min. (If you want change start run time, see 3-1 of the program menu.)
  - **Engine start turn OFF:** Press the button twice consecutively (Double click), the start turn OFF with 2 chirps in the vehicle.
  - **Start condition:** If you want to do remote engine start, all sensing (Door, trunk, brake, hood) must be normally operated. If start isn't operated at once, starting repeatedly your car 4 times by increase each 0.3 seconds.

## Reservation of stick shift vehicle (Auto process)

**Stick shift vehicle must keep on neutral position after driving.**

Remote engine start's function after reservation process is the same as the case of automatic vehicle.


### \* Start reservation process

- 
- Keep stick shift on neutral position after driving
- Remove the ignition key
- "1 chirp"
- Light 1 time (The engine will remain be running.)
- Open and close the door (The engine will remain be running.)
- Door lock and arming
- Press the button
- Finish the configuration. (Engine turn off)
- Notice**  
Gear must be keep on neutral position after driving for the safety.
- ARM**

- The start reservation is a process to confirm that gear is on neutral position in case of the stick shift vehicle.
- You can not use remote start without guarantee of neutral.
- **In case of canceling the reservation**
  - In case of remove the ignition key when doors are opened after driving.
  - In case you open the door after the reservation is completed.(The reservation is canceled for the safety because we can not guarantee that the gear is the neutrality.)




## Reservation of stick shift vehicle (Manual process)



### ● Factory set = Auto reservation

If you want to use the manual reservation process you must change to OFF 1-5 of the program menu.

## Getting on the vehicle during remote start



- **Engine start safety mode:** If you press the brake pedal at the remote start, engine start program will be completed with engine turn off.  
(This function will be only operated in case brake sensing wire is connected.)

# Start Functions(LPG)


## Start reservation of the LPG vehicle (Optional)

-In summer? The reservation is the same as normal vehicle kinds's.


-In winter? Remaining gas in gas line is frozen if the temperature falls below the zero.

For prevention it, you had better do as follows.

(This function is operated when you install LPG gas velb ON/OFF relay.)




## Getting on the vehicle during LPG start




### Notice

1. You must notice not to turn the ignition key to an "ST" location in getting on the vehicle during remote start.
2. Beware that engine start turn off within 1min if you not turn the ignition key to an "ON" but turn to an "ACC"



- **Engine start safety mode:** If you press the brake pedal at the remote start, engine start program will be completed with engine turn off.  
(This function will be only operated in case brake sensing wire is connected.)


## Time reservation start setting



- Use the function after start time setting (See 12 page start time setting)  
This function is operated only one time after the setting for the safety.  
(It is convenient if you use in the situation which remote control isn't operated.)  
In case of the stick vehicle, you can setting only after start reservation.
- Icon turn ON, if automatic start is setting.


**AUTO  
START**

## Vehicle selection mode




# Start Functions

## Auto turbo function




**TURBO** : This icon is turned on when turbo function is setting.

## VALET mode




- Use this function when you leave your car to other person that don't know how to use this transmitter.
- **In the case of the valet mode, you can operate only door lock/unlock and trunk open by transmitter.**
- Upper valet function is general method and Digital code valet function see the 19,26 page.

## Repeat start operation



- **This function is operated each every 3 hours.**  
The start time is operated for setting start time. (Default : 15 minutes.)


## ■ Button hold



- If the button hold mode is ON, **F** is displayed and user can operate only F & M button.


If you want to cancel it, press the F button for 2sec one more time. (**F** is OFF)

## ■ Signal check




- If the signal check mode is ON, ● is displayed and the transmitter check the communication condition by commuting with main control unit each every 60 min. If you want to cancel it, press the F button for 4sec one more time. (● is OFF)
- If the signal can not receive, the **IIIERR** icon will be displayed with buzzer sound.

## ■ Buzzer ON/OFF



- If the buzzer is OFF, (BZ) is displayed and the transmitter do not output any sound. If you want to cancel it, press the F button for 6sec one more time. ((BZ) is OFF)

## ■ Alarm ON/OFF




- If the alarm is ON, (ALARM) is displayed and the melody is outputted at setting time. If you want to cancel it, press the F button for 8sec one more time. ((ALARM) is OFF)

(See the 12 page : Alarm time setting)


# Setting Mode


- Transmitter will return automatically to current time if you don't press the button for 10sec after setting mode.

## Current time setting




## Alarm time setting




- Setting time is inputted in memory.
- The icon  is marked in transmitter when alarm is "ON".  
(See the 11 page : Alarm ON/OFF)

## Start time setting




- Set up time to need time reservation start. (Setting time will memory in the IC.)
- Set up by the transmitter when you need the time reservation start.  
(See the 9 page : Time reservation start setting)

## Timer function




- This function is convenient when confirmation of the parking time and driving time. (The timer is marked 12 hours to minute.)

## Siren ON/OFF




- When turned siren off, sound of the shock sensor is only stopped. (The state is displayed to the LCD 2-way transmitter.)

## Temperature check




## LCD Lamp ON/OFF



If the LCD lamp is OFF, the transmitter do not operate LCD lamp.

## Vibration mode



# Convenient Functions

## Aux-1 output



AUX-1 will be outputted for 1sec.  
If you want to output time, change to 3-5 of the program menu.

(One way transmitter  
: Press button 4(\*) for 2 seconds)

This icon is turned on when you operate AUX1 output.

## Aux-2 output



AUX-2 will be outputted for 1sec.  
If you want to output time, change to 3-6 of the program menu.

(One way transmitter  
: Press button 4(\*) for 2 times)

This icon is turned on when you operate AUX2 output.

## Smart access mode

- If the system setting is access mode, this icon is turned on.  
(Operation method is refer to the program menu 4-6, 21page. )

If you use this function, the transmitter battery life will be short.



## Convenience start



Step on the brake and  
press the button 2times

- If you step on brake and press 2times the START button when the car is starting, you can operate this function.  
If you operate this function, the car maintain starting mode for 15 minutes after get off the vehicle and operating ARM by transmitter. (If you change the program menu 3-1 start time, the convenience start time is change, too.)

## Cold & hot start




- This icon is turned on when temperature start is setting.  
(Operation method is refer to the program menu  
Cold & Hot start 1-7,18 page)




## Transmitter code learning

(The operation in the situation which the door is opened)



- This function is used when you lose transmitter or break down. You can use this function though siren is continually operated.
- The transmitter input is possible to each maximum 2pcs both one way and two way transmitter.

## RPM setup (Only used by the install engineer)



### ● RPM setup method

- Step 1. Engine ON and maintain idling condition. (600-700RPM)
- Step 2. Set the valet mode.
- Step 3. Press the door and M button simultaneously for 2seconds, then the idling condition is memory in main control unit. (This data is applied at remote start.)
- Step 4. Cancel the valet mode.



**NOTICE** If you install in tach pulse sensing wire (CN5 yellow), you have to operate RPM setup.

## Low battery indicator

- You must adjust current time again after battery interchange.
- If the operation range of transmitter is shortened or the buzzer sounding was lower than normal, please replace the battery to new one.
- The alkaline battery life is 2~3 months and exchange the battery at once if the icon blinks.



Display

# Program Setting

## Program setting

Program setting method is different according to transmitter.

(Two-way and One-way transmitter)

Transmitter must be disarm at the program setting.

### LCD 2-WAY TRANSMITTER




- If you want change of the system program,
- STEP1. Press the F button 3times.
  - STEP2. You can change to menu of the P-1, P-2, P-3, P-4 by press the M button.
  - STEP3. Choose the function you want by press the trunk button.
  - STEP4. Choose the program state by press the button 1(ON) or button 2(OFF).
  - STEP5. Function you choose will be transmit a main and setting is completed by press the F button.

### ONE-WAY TRANSMITTER

One-way transmitter can be change only in P-1 and P-2 of the program menu.

Program menu step is marked by chirp sound.(ex: Menu 1-1 = 1 Chirp, 1-2 = 2 Chirps, ..)



## Program reset

- **Program reset of the main control unit:** If you press **1 and 3 button** simultaneously for 2 seconds within 30sec after ignition OFF at the valet mode, all program will default setting.
- **Program reset of the LCD transmitter:** If you reset main control unit, you must reset of the transmitter. Put battery in with press **M button** after remove the battery of the transmitter and then all program of the transmitter will default setting.

Program menu	LCD Display	P-1 Start Function	Factory Default	Optional
			Set up - Button 1 or 2	
1-1	<b>tur</b>	Auto turbo timer program	<b>OFF</b>	ON
1-2	<b>StL</b>	Door re-lock after remote start	<b>OFF</b>	ON
1-3	<b>ACC</b>	Trunk output change(At remote start)	<b>OFF</b>	ON
1-4	<b>LPG</b>	LPG function setting	<b>OFF</b>	ON
1-5	<b>Atr</b>	Auto reservation of stick vehicles	<b>ON</b>	OFF
1-6	<b>HEt</b>	Glow plug sensing for diesel engines	<b>OFF</b>	ON
1-7	<b>tEm</b>	Cold & hot start	<b>OFF</b>	ON
1-8	<b>IGt</b>	IG2 output ON/OFF at disarming	<b>ON</b>	OFF

Program menu	LCD Display	P-2 Basic Function	Factory Default	Optional
			Set up - Button 1 or 2	
2-1	<b>CCH</b>	Digital code valet mode	<b>OFF</b>	ON
2-2	<b>IGL</b>	Ignition lock/unlock	<b>OFF</b>	ON
2-3	<b>PSA</b>	Passive arming	<b>OFF</b>	ON
2-4	<b>PSL</b>	Passive lock	<b>OFF</b>	ON
2-5	<b>LdA</b>	Last door arming	<b>OFF</b>	ON
2-6	<b>CHP</b>	Chirp sound	<b>ON</b>	OFF
2-7	<b>dUP</b>	Double door unlock pulse	<b>OFF</b>	ON
2-8	<b>dLP</b>	Double door lock pulse	<b>OFF</b>	ON

Program menu	LCD Display	P-3 Timing Function	Factory Default	Optional
			Set up - Button 1 or 2	
3-1	<b>Stt</b>	Run time for remote start	2 10 <b>15</b> 25 35 45	Minutes
3-2	<b>Std</b>	Standby time for starter operation	<b>4</b> 8 12 15 18 20	Seconds
3-3	<b>Sto</b>	Crank time for the tach/Noise sensing	<b>0.7</b> 1.0 1.2 1.5 2.0 3.0	Sec.
3-4	<b>CSt</b>	Cold start temperature setting	-4 -8 -12 -16 <b>-20</b> -24	(°C)
3-5	<b>Au1</b>	Aux 1 output LCH=Continue	<b>1</b> 5 10 20 40	(Sec.) Continue
3-6	<b>Au2</b>	Aux 2 output LCH=Continue	<b>1</b> 5 10 20 40	(Sec.) Continue
3-7	<b>ttt</b>	Turbo time setting	1 <b>2</b> 3 5 8 10	Minutes
3-8	<b>Amd</b>	Arm delay time setting	<b>5</b> 10 15 25 35 45	(Sec.)

Program menu	LCD Display	P-4 Advanced Function	Factory Default	Optional
			Set up - Button 1 or 2	
4-1	<b>SPo</b>	Siren pulse output	<b>OFF</b>	ON
4-2	<b>AEd</b>	Automatic engine disable	<b>OFF</b>	ON
4-3	<b>Lot</b>	Door lock/unlock pulse for 3.5 seconds	<b>OFF</b>	ON
4-4	<b>BPs</b>	Bypass ON/OFF	<b>OFF</b>	ON
4-5	<b>dom</b>	Dome light is changed to armed output	<b>OFF</b>	ON
4-6	<b>SAC</b>	Smart access mode ON/OFF	<b>OFF</b>	ON
4-7	<b>CAS</b>	NC	<b>ON</b>	OFF
4-8	<b>ACd</b>	Arm cancel mode at door open	<b>OFF</b>	ON

## ■ Program Menu P-1 for Start Function

### ● 1-1 Auto turbo timer program

When turned ON, this is function for maintain engine on for 2mins after the door is locked. You can change the turbo time at program setting 3-7(17page). (This is in use to aid function of the turbo vehicles.)

See 10page about the turbo function.

### ● 1-2 Door re-Lock after remote start (Only used by the install engineer)

When turned ON, door lock will be operated after engine turn off.

### ● 1-3 Trunk output change(At remote start) (Only used by the install engineer)

When turned ON, (+) will always output at the remote start.

### ● 1-4 LPG function setting(Optional)

When turned ON, the engine will turn off automatically within 30sec if LPG in gas line is empty when the engine turn off.

See 8page about the LPG function.

(This function is operated when you install LPG gas valve ON/OFF relay.)

### ● 1-5 Auto reservation of stick vehicles

In the default setting, this function is start program of the stick vehicle.

See 6, 7 page about the reservation of stick shift vehicle.

### ● 1-6 Glow plug sensing for diesel engines (Only used by the install engineer)

When turned ON, starter motor is operated after glow plug is OFF at the remote start. You must connect No.11 VIOLET wire of the connector CN 5.

### ● 1-7 Cold & hot start

When turned ON, engine automatically start if temperature become -20°C or +50°C at the arm mode. You can change the cold start temperature at 3-4.

This function is automatically off after total 8times operation.

This function will restart if transmitter become arm after disarm.

### ● 1-8 IG2 output ON/OFF at the disarm (Only used by the install engineer)

When turned OFF, IG2 is OFF at the disarm during remote start.

This function prevent from short in key box when the ignition key is turned ON during the vehicle remote start. In the default setting(ON), IG2 maintain ON.

(See 7page.Getting on the vehicle during remote start)

## ■ Program Menu P-2 for Basic Function

### ● 2-1 Digital code valet mode

In the default setting: Valet is operated to ON/OFF if you press the valet button for 5seconds at the ignition key ON. (See 10page about the valet mode.)

When turned ON: You can use the digital code valet function.

**Operating method** (Code is same to digital door lock code. See 26page.)

- STEP 1. Press the switch for 5seconds when the digital control module is standby mode, and then LED blinks one time and the display segment is rotated fast.  
(This function is maintained for 30 seconds.)
- STEP 2. Knock the sensor more than 5 times after get off the car within 30 seconds, then the digital code start count. (If you press the switch again within 30 seconds, LED blinks 2 times and digital valet function is canceled.)
- STEP 3. During the numbers automatically count with delay each 2 seconds from 0 to 9, knock the sensor at the registered CODE. Then selected number blinks 5 times and it automatically repeat next number from "0".
- STEP 4. Select the remainder 3 CODES as upper STEP 3.  
If you select all CODES in order, valet mode is ON.

If you want to cancel the valet mode, press the valet button for 5 seconds at the ignition key ON.

### ● 2-2 Ignition lock/unlock

When turned ON, the doors will be locked when step on brake after the ignition is turned ON. The doors will be unlocked when the ignition is turned OFF.

Getting on the vehicle during remote start: Door is locked when ignition key ON and then step on the brake.

### ● 2-3 Passive arming

When turned ON, the system will arm automatically after 30seconds if the ignition key is OFF and door open/close.

### ● 2-4 Passive lock

When turned ON: When the system is arm by passive arming, door lock will be automatically operated.

### ● 2-5 Last door arming CAUTION

When turned ON, if all door is closed at the disarm, door lock will be operated with arm after 30seconds.

### ● 2-6 Chirp sound

In the default setting, siren of the vehicle will output chirp sound when you operate transmitter.

### ● 2-7 Double door unlock pulse (Only used by the install engineer)

When turned ON, door unlock output will output 2times whenever unlock.

- **2-8 Double door lock pulse** (Only used by the install engineer)  
When turned ON, door lock output will output 2times whenever lock.

## ■ Program Menu P-3 for Timing Function

- **3-1 Run time for remote start**  
This function adjust run time of the vehicle when remote start, cold start and time reservation start.
- **3-2 Standby time for starter operation**  
This function adjust delay time until starter motor is operated when remote start, cold start and time reservation start.
- **3-3 Crank time for the tach or noise sensing** (Only used by the install engineer)  
This function adjust operation time of the starer motor when remote start by tach or noise sensing.
- **3-4 Cold start temperature setting**  
When turn ON program menu 1-7, you can change the cold start temperature. Default setting is -20°C.
- **3-5 Aux 1 output** (Optional : Only used by the install engineer)  
In the default setting, Aux 1 will output in main for 1second when you operate Aux 1 by transmitter. You can change the Aux 1 output time.  
If you set to LCH (Continue), Aux 1 will be continuously output before you operate Aux 1 by transmitter again.
- **3-6 Aux 2 output** (Optional : Only used by the install engineer)  
In the default setting, Aux 2 will output in main for 1second when you operate Aux 2 by transmitter. You can change the Aux 2 output time.  
If you set to LCH (Continue), Aux 2 will be continuously output before you operate Aux 2 by transmitter again.
- **3-7 Turbo time setting**  
When you use the auto turbo timer program(P1-1), you can change the turbo time. Default setting is 2minutes.
- **3-8 Arm delay time setting**  
When you operate arming(4page), you can change delay time of sensing(door, trunk, hood) after door is locked. (Shock sensing is add 20 seconds to delay time.)

## ■ Program Menu P-4 for Advanced Function

### ● 4-1 Siren pulse output

In the default setting, siren will be continually outputted for 30seconds when alarm is operated. When turned ON : Siren will be outputted to pulse.

### ● 4-2 Automatic engine disable(Optional)

When turned ON, starter kill will be automatically outputted 30seconds after ignition OFF with LED blink slowly.

### ● 4-3 Door lock/unlock pulse for 3.5 seconds(Only used by the install engineer)

When turned ON, door lock/unlock will be outputted for 3.5 seconds.  
Default setting: 0.8 seconds

### ● 4-4 Bypass ON/OFF

When turned ON, if door/hood/trunk is sensed before arm delay time(P3-8), the siren will output 3 chirps after arm delay time, and then inform to transmitter. In the default setting, if door/hood/trunk is sensed before arm delay time(P3-8), the siren will be outputted after arm delay time. (Default is bypass function OFF.)

### ● 4-5 Dome light is changed to armed output(Only used by the install engineer)

When turned ON, dome light output(CN5 black wire)is changed to always output during arming.

### ● 4-6 Smart access mode ON/OFF

When turned ON, LCD display ACCESS icon. And the main control unit sense the transmitter when transmitter is near by vehicle, the system will be automatically disarm (Unlock). If the transmitter is far from vehicle, the system will be arm. If you use this function, the transmitter battery life will be short.

### ● 4-7 NC

### ● 4-8 Arm cancel mode at door open

When turned ON, if the door is open, arm is not operated by transmitter. In this case, you can operate arm after closing the door.

## HARNESS WIRE CONNECTION GUIDE

- Please read this entire installation guide before the installation.
- Do not disconnect the battery if the vehicle has the anti-theft-coded radio.
- Test all circuits with a high-quality digital multi-meter before making connections.
- Vehicle anti-theft systems(immobilizers) require a bypass module.

The bypass module allows for easy interfacing, while still maintaining the OEM security system's integrity.

### CN1 6Pin Heavy Gauge Harness

---

#### 1. White(+) Starter Output

Connect this wire to the starter wire in the vehicle.

#### 2. Black(-) Ground

Connect this wire to a clean, paint-free sheet metal location.(driver kick panel)

#### 3. Blue(+) 2nd Ignition Output

Connect the wire to the second ignition wire in the vehicle.

#### 4. Green(+) IG3 Output(Contemporary output with GRAY of the CN4)

This output can be used according to vehicles at the remote start.

And this wire output after 1 minute after remote start is operated.

#### 5. Red(+) 12V Constant Input

Must be connected to a high current source. Since the factory supplies(+)12V to the key switch. That is used to operate the motor, it is recommended that these wire be connected there.

#### 6. Yellow(+) Ignition Output

Connect this wire to the ignition wire in the vehicle.

### CN2 5Pin Output Harness

---

#### 1. White(+) Light Flash Output

This wire should be connected to the (+) parking light wire.

#### 2. White(+) Light Flash Output

This wire should be connected to the (+) parking light wire.

#### 3. Orange(+/-) Trunk Unlock Programmable Output(Optional)

This output is used to trunk unlock.

If you change to (-) jumper 4 of the control box, orange wire will output (-).

- Additional Ignition output: If you change to ON 1-3 of the program menu, orange wire will output at the remote start.  
At this time you can't use trunk unlock output.



## 4. Brown(+)Siren Output

Connect this wire to the (+)wire of the siren.

## 5. Green(-)Status Output(Optional)

This come in one second before ignition on and continues until one second after ignition off.(Use the immobilizer bypass module or LPG relay.)

## CN3 2Pin Door Lock/Unlock Harness(High Power Output)

### 1. Green(+/-)Lock Output(10A)

This wire will output door lock/unlock motor when you lock the door by the transmitter.

### 2. Blue(+/-)Unlock Output(10A)

This wire will output door lock/unlock motor when you unlock the door by the transmitter.

## CN4 6Pin Lock/Unlock & Output Harness(Low Power Output)

### 1. Green(-)Lock Output(-250mA)

This wire output -250mA when you operate "DOOR LOCK(ARM)" by the transmitter and this must be connected to (-)signal line of the door lock circuit that installed in vehicles.

### 2. Blue(-)Unlock Output(-250mA)

This wire output -250mA when you operate "DOOR UNLOCK(DISARM)" by the transmitter and this must be connected to (-)signal line of the door unlock circuit that installed in vehicles.

### 3. Black(-)2nd Kill Output(-250mA)(Optional)

This wire output the opposite No.1 (White wire)Starter kill output of Cn5.  
And this wire can be used when you ignition or fuel pump circuit cut off.

### 4. White(-)Horn honk Output(-250mA)(Optional)

This wire is not outputted at shock sensing, only outputted when the door, trunk and IG sensing(In ARM mode). This output signal is outputted 1 second ON and 1.5 second OFF for 30 seconds.

### 5. Gray(-)IG3 Output(-250mA)(For GSM)(Optional)

This wire always output with GREEN wire of the connector CN1.  
And this wire output after 1minute after remote start is operated.

### 6. Brown(-)Preliminary Start Input(For GSM)(Optional)

Engine is started if (-)pulse is inputted in condition that remote start is operated.  
This function is operated same as the remote start function.  
If (-)pulse is inputted when engine is ON, engine become OFF.  
Signal pulse length is suitable from 0.5 to 3 seconds.

## CN5 12Pin Output/Input Harness

### 1. White(-) Starter Kill Output(Optional)

The WHITE wire is pre-wired to control the starter kill relay.

This wire supplies a (-)250mA ground as long as the system is armed.

But kill out is not outputted at the remote starter.

And this output ceases as soon as the system is disarmed.

NOTE: If using the WHITE wire to activate an add-on accessory such as window automation, pager or voice module a 1 Amp diode must be installed to ensure proper operation.

IMPORTANT! Never interrupt any wire other than the starter wire.

### 2. Black(-250mA)Dome light Output(Optional)

Connect this wire to the optional dome light supervision relay.

IMPORTANT! This output is only intended to drive a relay. It cannot be connected directly to the dome light circuit, as the output cannot support the current draw of one or more bulbs.

When turned ON of **4-5 Dome light is changed to armed output**, dome light output(CN5 black wire)is changed to always output during arming.

### 3. Brown(-250mA)Aux1 Output(Optional)

This wire provides a (-)250mA output(1 second) whenever the transmitter button(s) controlling Aux1 is pressed.

You can change to output time in 3-5 of the program menu.

### 4. Green(-)Trunk Sensing(Optional)

This input will respond to a negative input with an instant trigger.

Also this wire connect to trunk pin switch.

### 5. Gray(-)Hood Sensing(Optional)

This wire must be connected to hood pin switch. This input will disable or shut down the remote start when the hood is opened. It will also trigger the security system if the hood is opened while the system is armed.

**This wire can be used to (-)Brake sensing.**

### 6. Blue(- or +)Door Sensing

Most vehicles use negative door trigger circuits. Connect the BLUE wire to a wire showing ground when any door is opened. When connecting to newer model vehicles there is generally a need to use individual door triggers.

Use when change to Jumper 3 is (+)setting: This type of dome circuit is used in many Ford products. Connect the BLUE wire to a wire that shows (+)12V when any door is opened.

## 7. Red(+)Alternator Sensing

This wire check start status of the vehicles.

Connect to the Lamp terminal of the generator.

This wire must be inputted (+) when engine of the vehicle is starting.

And this wire don't connect in case noise mode or tach pulse sensing.

## 8. Yellow(Tach Pulse)Enging Sensing

This wire connect to tachometer sensing wire or ignition coil(-)wire and so on. Therefore connect to wire that pulse is outputted when engine is operated. And this wire don't connect in case noise mode or alternator sensing.

## 9. Sky Blue(-250mA)Aux2 Output(Optional)

This wire provides a (-)250mA output(1 second) whenever the transmitter button(s) controlling Aux2 is pressed.

You can change to output time in 3-6 of the program menu.

## 10. Pink(+) Ignition2 Sensing(Preliminary)

This wire is preliminary wire for sensing ignition2.

This wire need not connect because sense by ignition2 output when 2nd ignition output of the connector CN 1 is normally connected.

## 11. Violet(+ or -)Glow Plug Sensing(Optional)

In diesel vehicles it is necessary to interface with the wire that turns on the "wait to start light" in the dashboard. This wire illuminates the bulb until the vehicle's glow plugs are properly heated. When the light goes out the vehicle can be started. This wire is always available at the connector leading to the bulb in the dashboard. It can also be found at the engine control module (ECM) in many vehicles. However, there are some instances of diesel vehicles without "wait to start light" wires. If this wire become (-)status when "wait to start light" is on, you must setting to (-) jumper 2 of the main PCB.

## 12. Orange(+)Brake Sensing

This wire must be connected to the vehicle's brake light wire. This is wire that shows (+)12V when the brake pedal is pressed. The remote start will be disabled or shut down any time the brake pedal is pressed.

(-)Brake sensing can be used instead of #5 (-)Hood sensing wire of the CN 5.

## CN6 3Pin Shock Sensor Cable

Inputs shorter than 0.6 seconds will trigger the warning, while inputs longer than 0.6seconds will trigger full alarm(30 sec).

## CN7 4Pin Digital control module(Optional)

### -Digital door unlock/lock, digital/manual valet, LED, driver call function

- User can unlock the door without transmitter by input the secret code that user register.
- User can operate door lock function to simple operation without transmitter at the parking.
- If you input the wrong code, the security function is operated.

## 1. OPERATING (Digital code valet operation is refer to P2-1, 19page.)

Operation of all function must be started in the standby mode that the display segment slowly rotate.

### 1)DOOR LOCK

STEP 1. If you press the switch one time in the standby mode, LED blinks one time and the display segment is rotated fast.

(This function is maintained for 30 seconds.)

STEP 2. Knock the sensor more than 5 times after get off the car within 30 seconds and close the all doors, then door will be locked.

(If you press the switch again within 30 seconds, LED blinks 2 times and lock function is canceled.)

### 2)DOOR UNLOCK

STEP 1. Knock the sensor more than 5 times at the standby mode.

(The call function is operated one time at the first knock.)

STEP 2. During the numbers automatically count with delay each 2 seconds from 0 to 9, knock the sensor at the registered CODE. Then selected number blinks 5 times and it automatically repeat next number from "0".

STEP 3. Select the remainder 3 CODES as upper STEP 2.

If you select all CODES in order, door open function is operated.

**CAUTION:** If you input a wrong code 5 times within one hour, "U" is marked and all functions are stopped for one hour.



If you press the switch, this function is canceled.

### 3)SECRET CODE REGISTRATION

STEP 1. Press the switch 20 times at standby mode and then LED blinks 2 times.

STEP 2. Knock the sensor more than 5 times within 30 seconds.

During the numbers automatically count with delay each 2 seconds from 0 to 9, knock the sensor at a number you want. Then selected number blinks 5 times and it automatically repeat next number from "0".

And if you input consecutively all 4 numbers as upper STEP 2, a new code is inputted.

If you want to change the secret CODE, you have to just repeat STEP 1-2.



**CAUTION:** User's secret code must be registered by user.

(Factory setting code is "1234".)

## 2. Installation

- 1)4pin Cable: Connect to main control box.
- 2)Installation location: First of all, stick the sticker on the inside the windshield of the wheel, and stick the control module on that sticker.
- 3)Sensitivity adjustment: If you turn the volume under the switch to the right, sensitivity of knock will be more sensitive.(Normal location: Center)
- 4)Secret code reset: If you put on the 4pin cable again with press the switch, secret CODE is changed to "1234".

### Cn8 5P Receiver cable

---

#### Mounting the Receiver/Antenna

he best location for the receiver/antenna is centered on left of the front windshield. The antenna should be mounted horizontally.

Metallic window tint can also affect range, so this should be a consideration when determining the mounting location.

#### After determining the best mounting location, follow these steps:

1. Clean the mounting area with a quality glass cleaner or alcohol to remove any dirt or residue.
2. Plug the 5 pin cable into the receiver/antenna.
3. Mount the receiver/antenna using the supplied double-sided tape.
4. Plug the receiver/antenna cable into the main control unit.

### CN9 2P Valet Switch (Optional)

---

The Valet button should be accessible from the driver's seat. It plug in to the CN 9 on the side of the main control unit.(Normal valet function)

### CN10 2P LED Indicator (Optional)

---

Mountain the LED indicator in a visible location such as dash or console. Plug the LED into the control module.

# Installation

## Switch and Jumper Settings

### 1) Set up a start sensing

Start sensing is fixed up alternator signal input in the default setting. And if you want sense engine status to other methods (the noise or tach pulse sensing), see the under.

**(A) Alternator sensing: Dip 1 = OFF, Dip 2 = OFF and set to alternator jumper 1.**

That mean noise sense if red LED is ON.



DIP-2: OFF

DIP-1: OFF



Jumper 1

<Input delay time (VR1) adjustment for the alternator sensing>

This is used when you want lengthen operation time of the start motor in case you install alternator sensing method. (Turn to the right if you want lengthen operation time.)

**(B) Noise sensing: Dip switch 1 is ON and change to noise jumper 1.**

That mean noise sense if red LED is ON.



DIP-2: OFF

DIP-1: ON



Jumper 1

Vehicles that noise is sensed is do not use noise sensing mode when you turn to "ON" IG key with engine is not started. Noise check method is that you have to see RED LED of main control PCB. This LED must be become "ON" only when engine is started. If LED is become "ON" when engine is not started, you must use another method (alternator, tach pulse sensing).

**(C) Tach pulse sensing: Dip switch 2 is ON.**

That mean pulse sense if yellow LED blink.



DIP-2: ON

DIP-1: OFF



NOTICE

If you install in tach pulse sensing wire (CN5 Yellow), you have to operate RPM setup.

(See the 15 page : RPM setup mode)

### 2) Brown Jumper wire

In case use automatic gear vehicles, this wire must be cut.

You must not cut this wire in case manual gear vehicles.

(Factory set = Manual gear type)



CAUTION

DO NOT CUT BROWN JUMPER WIRE  
IN CASE MANUAL GEAR VEHICLES

● **Status memory function:** System status will maintain if even power of the main control unit become OFF and then ON.

(Arm - 1 chirp, Disarm - 2 chirps, Valet - 3 chirps)

## Switch and Jumper Settings

Trunk Output  
(To CN 2: Orange)

⊖ Jumper 4 ⊕

Door Sensing  
(From CN 5 : Blue)

⊕ Jumper 3 ⊖

Glow Plug Sensing  
(From CN 5: Violet)

⊖ Jumper 2 ⊕

DIP 2-ON: Tach Pulse Sensing  
(From CN 5: Yellow)

DIP 1-ON: Engine Noise Sensing  
(On PCB)

OFF: Alternator Sensing  
(From CN 5: Red)

Engine Sensing

Jumper 1

Noise ↔ Alternator

Indicating for Tach pulse input

LED

Yellow

LED

Red

Indicating for noise or alternator input

Adjustment of the Input Delay Time  
(At the alternator Sensing)

VR1

W1 Brown jumper wire

Normal=Manual Cut=Auto

CN 1	4 Green	1 White
	5 Red	2 Black
	6 Yellow	3 Blue

CN 2	1 White
	2 White
	3 Orange
	4 Brown
	5 Green

CN 3	1 Green
	2 Blue

CN 4	1 Green
	2 Blue
	3 Black
	4 White
	5 Gray
	6 Brown

CN 5	7 Red	1 White
	8 Yellow	2 Black
	9 Sky Blue	3 Brown
	10 Pink	4 Green
	11 Violet	5 Gray
	12 Orange	6 Blue

CN 6	1 Red
	2 Blue
	3 Black

- 1 (+) Starter Output(30A)
  - 2 (-) Ground
  - 3 (+) 2nd Ignition Output(30A)
  - 4 (+) IG3 Output(30A): Contemporary output with GRAY of the CN4
  - 5 (+) 12V Constant Input
  - 6 (+) Ignition Output(30A)
- 
- 1 (+) Light Output(10A)
  - 2 (+) Light Output(10A)
  - 3 (+ or - ) Trunk unlock or additional ignition Output at Remote Start(10A)
  - 4 (+) Siren Output(2A)
  - 5 (-) Status Output(250mA)  
: Bypass unit, LPG relay
- 
- 1 (+/-) Lock Output(10A)
  - 2 (+/-) Unlock Output(10A)
- 
- 1 (-) Lock Output(250mA)
  - 2 (-) Unlock Output(250mA)
  - 3 (-) 2nd Kill Output(250mA)
  - 4 (-) Horn honk Output(250mA)
  - 5 (-) IG3 Output(250mA) (For GSM)
  - 6 (-) Preliminary Start Input (For GSM)
- 
- 1 (-) Starter Kill Output(250mA)
  - 2 (-) Dome light (Armed) Out(250mA)
  - 3 (-) Aux1 Output(250mA)
  - 4 (-) Trunk Sensing
  - 5 (-) Hood Sensing (-) Brake sensing  
can be used instead of this wire.
  - 6 (- or +) Door Sensing
  - 7 (+) Alternator Sensing
  - 8 (Tach Pulse) Engine Sensing
  - 9 (-) Aux2 Output(250mA)
  - 10 Ignition2 Sensing(Preliminary)
  - 11 (+ or -) Glow Plug Sensing
  - 12 (+) Brake Sensing

- 1 (+) 12V DC
- 2 (-) Sensor Input
- 3 (-) Ground

Shock sensor



Digital Control Module (Optional)



Receiver Module

LED (Preliminary) VALET(Normal valet function) (Preliminary)

## Remote Start & Security System



**Köpel**